

# Lumina 200

## LUM-200-ORL

Lighting can create a powerful, impactful presence or display. Illumination is an important piece of the puzzle to achieve the mood, style and staging that you desire.



We are continually improving and modifying our product range and reserve the right to vary the specifications without prior notice. All dimensions and weights quoted are approximate and we accept no responsibility for variance. E&OE. See Graphic Templates for graphic bleed specifications.

## features and benefits:

- 110 volt ETL approved wall washer floodlight with a straight arm & adjustable head
- light includes 120 watt halogen bulb
- silk black finish
- Ideal for Popups
- Light comes with cord pre-attached
- One year warranty against manufacturer defects

## dimensions:

Hardware	Safety
<p>Assembled unit: 19.5" (495.3mm) long from end to end</p>	<p>Read all instructions WARNING! To reduce the risk of fire, electric shock or injury to persons:</p> <ul style="list-style-type: none"> <li>- Minimum distance to lighted object: 16" (.5mm)</li> <li>- Input: 120V, 60Hz</li> <li>- CAUTION: Risk of fire - Use 120 watt or smaller double ended halogen lamp type T-3, 110 volt</li> <li>- CAUTION: To reduce risk of a burn during replacing bulb, disconnect power to the unit by unplugging before bulb replacement.</li> </ul>
<p>Shipping</p> <p>Shipping dimensions - packed in a box: 24"l x 8"w x 8"h 610mm(l) x 203mm(w) x 203mm(h)</p> <p>Approximate shipping weight: 2 lbs / 0.9 kg</p>	<ul style="list-style-type: none"> <li>- Keep fixture away from combustible materials</li> <li>- Replace cracked protective shield immediately. Do not use fixture without the shield being installed.</li> <li>- To reduce the risk of exposure to excessive UV radiation, do not remain under light if skin feels warm.</li> <li>- Protect the fixture from impact, scratching or abrasions.</li> <li>- If the cord-set becomes damaged, replace the cord-set before using fixture.</li> </ul>

## additional information:

**To Remove Lamp:** Turn off/unplug fixture and allow to cool before replacing lamp. Bulb gets hot quickly. Do not touch hot bulb or shade. Unscrew two small finger screws that hold glass cover in place. Bulb is spring loaded on both ends. Simply push in one end and gently pull bulb out. Take care to use a soft cloth as oil from skin can damage the bulb.

**To Fit or Replace Lamp:** Take the bulb out of the box taking care not to touch the bulb with your bare fingers. Oil from skin can damage lamp. Use a soft cloth when grasping lamp. Open the fixture by unscrewing the two finger screws. Insert bulb into the fixture. Bulb is spring loaded on both ends. Push one end in and gently slide other end into place.